

Rolls Neo – 19mm, 28mm, 35mm diameters

Installation Information for Bay Windows

	FITTING NOTES Right angled bay windows need a corner segment as per image on left of approx 15cm to allow the flow of the rings around the corner. A corner joint needs to go at each end of the segment. Each Bend needs to be supported with a passing bracket approx 10cm before and after the corner joint. Pole sits on front cutaway edge of the passing bracket and only rests on it. If competent at DIY you could drill through bracket and use self-tapping screw to secure bracket to pole if preferred
INSTALLATION NOTES Keep "clean" uncut ends for corner joints wherever possible. Quality of join is important to achieve the smooth running of rings over the joints. Ensure the cut is straight and de-burr any rough edges.	

